



Applying GageCarve to a Flat or Slightly Radiused Surface

1. Make sure all materials are acclimated to room temperature.
2. Prepare surfaces for adhesive according to the adhesive manufacturers' recommendations.
3. Scuff the back of the GageCarve panel for better adhesion to the anodized surface.
4. Apply adhesive as instructed by the adhesive manufacturer.
5. Apply GageCarve and secure with pressure for the recommended curing time.
6. Remove pressure and clean any adhesive residue.
7. If mounting onto MDF a balancing backer is recommended to stabilize.